

# Wall Graphics

## Preparation Guide

**SIGNWAVE**<sup>®</sup>  
So much more than signs.™

- Repair any existing wall damage (holes, loose wallboard joints, chipped or peeling paint) to return it to like new condition.
- Clean the wall prior to priming and painting.
- Prime the wall with a primer that is compatible with the top paint coat. Two coats may be required.
- Paint the wall with a quality, semi gloss top coat. Do not use matte paint or paint with silicone, graffiti-resistant or texturing additives.
- Use a short nap roller.
- Allow the primer and paint to dry/cure as recommended by the primer/paint manufacturer, but no less than 5 days. Full curing requires at least 30 days in proper conditions.
- DO NOT USE solvent based products to clean interior paint surfaces. Interior paints are usually water-based. Using a harsh cleaner can damage your painted surface. Wipe clean with lint free cloth or towel and proceed to application process.



Ensure surface is clean and undamaged prior to installation



'Nap' refers to the thickness of the roller material



Do not apply graphics to any wall that does not have excellent paint to substrate bonding.

### Checklist

- Has the wall been primed?
- Has the wall been painted with the required paint and roller?
- Has it been a minimum of 5 days since the wall was painted?

If you require further assistance, please contact your local SIGNWAVE centre

SWA\_2020